## **Center for Cellular Profiling: Cytometry and Single-Cell Multiomics** *Brigham & Women's Hospital*

	Xenium FFPE Slide Preparation
Sample	FFPE block
Slides (NOTE: request from us prior to sectioning)	Xenium Slides (stored at -20°C equilibrate to RT 30 minutes prior to sectioning) We will provide Xenium slides for your project
Tissue Sectioning (NOTE: Total Sample Area inside the fiducials is 10.45mm x	<ul> <li>Rehydrate block in an ice bath (Milli-Q water) for 10-30 minutes.</li> <li>FFPE blocks should be sectioned at 5 µm thickness. Discard the first few sections.</li> <li>Float sections in 42°C water bath.</li> <li>Tissue should not cover the marked fiducials, especially the fiducials at the top, bottom, and corners.</li> </ul>
22.45mm)	Sample Area (do not cover fiducials, especially within red shaded area) PR:300941 Xentum V1 Xentum V1 Xentum V1 Xentum V1
After sectioning	<ul> <li>After sectioning and prior to use or storage, to avoid RNA degradation and improve tissue adherence:</li> <li>Dry upright at RT until tissue is opaque and no water is seen on/under the section.</li> <li>Bake slides at 42°C for 3 hours.</li> <li>Dry in a desiccator overnight at RT.</li> </ul>
Storage	• Slides can be left in a desiccator at RT for up to 4 weeks.